



Notes

Use 3000 psi concrete in pad.

Wire mesh shall stop 3" from sides.

Where metal stubout is required, ground with no. 2 bare copper.

Drill pad and install 3/8" anchor bolts using 3/8" lead anchors as transformer or feed-thru enclosure is being installed.

Backfill all ditches under pad with gravel.

PES will perform a pad inspection before concrete is poured and after the form is removed.

If any ditch does not reach the required depth, the conduits are to be covered with 6" of concrete.

If a ditch crosses another utility, PES is to be located in the lower position and 6" of concrete separation is required. The concrete is to extend 18" either side of the crossing.

No ditch is to be covered until PES has performed an inspection and pulled a warning tape.

Pulaski Electric System
Typical 1-Phase Transformer Pad

revised March 2010