



1. 2/0 BARE COPPER GROUNDING WIRE TO BE PLACED UNDER PAD BEFORE PAD IS POURED.
2. WIRE TO BE BONDED TO GROUND RODS WITH HEAVY BOLTED CLAMP.
3. LEAVE SLACK IN BARE CU GROUND WIRE IN HIGH AND LOW SIDE CAVITIES FOR PES TO ATTACH TO.
4. INSTALL CONDUIT GROUNDING BUSHING FOR EACH STEEL PRIMARY CONDUIT.
5. ALL MATERIAL ON THIS SHEET TO BE FURNISHED BY CUSTOMER UNLESS OTHERWISE SPECIFIED.

Note:
 This spec is to be used in conjunction with the general 3phs pad spec.

PULASKI ELECTRIC SYSTEM TYPICAL FOR CONCRETE PAD

Location:		
Trans. 500 / 750kva	Gal. oil	LB.
Maker	Manufacture date	
S/N		
Voltage 120/208 or 277/480	Taps no	
%Z 1.5	Fault Current	